

Bolsa Adventure Ksix Para Cámaras Deportivas Y Accesorios Pequeña (250x180x70 Mm) Roja

DESCRIPCIÓN

The Ksix Adventure Bag is perfect to transport your action camera and its accessories. Its material is resistant to water and humidity so you can carry it under the rain or inside an humid place without worrying about your equipment. Its inner removable velcro dividers allows you to customize the inside of the bag adjusting it for the equipment and accessories you use. Technical informationGreat solution to store and carry around your action camera and its accessoriesWater resistantInner dimensions: 240 x 175 x 50 mmRigid exterior and padded interiorInside pocket with elastic trim. Great for cable storageRemovable velcro dividers. Customize the compartments to fit the size of your camera and its accessoriesCompatible with action camera and GoPro



Rojo Color

TPU Material

PUNTOS FUERTES (strengths)



(S)X REF. BXGOBAG02RJ **EAN**: 8427542064604